




## THE RUGBY BALL LIGHT

Replica size 5 England rugby ball light.



1. 'Kickers Tee' lamp base & switched cable.
2. E27(ES) 26W (max) CFL - not supplied.
3. Twist lock ball envelope.



INTERIOR  
ILLUMINATION  
ONLY

**WARNING:**  
THIS IS NOT  
A TOY OR  
SPORTS  
PRODUCT



### Keep this card for future reference.

Be sure to read, follow and understand these warnings and instructions before using this light.

#### Warning:

- To avoid the risk of suffocation keep all packaging away from children.
- For use with E27(ES) Compact Fluorescent Lamp **ONLY**. 26W (max). Not supplied.
- Do **NOT** use a standard filament lamp.
- The light is for **INTERIOR** illumination only.
- The markings on the ball are for illustration only. Do **NOT** attempt to inflate the ball.
- **ALWAYS** unplug the light before removing the twist lock ball envelope to install/replace the lamp.
- Wipe clean with a soft dry cloth. Do not use abrasive cleaners as this will damage the finish.
- If the switched cable is damaged, to avoid the risk of injury, it **MUST** only be replaced or repaired by a suitably **QUALIFIED PERSON**.
- The light is not a toy\* or for use as a rugby ball.

\*This product is **NOT** adapted for use in play by children under 14 years old.

#### Instructions:

1. Disconnect the light from the power supply.
2. Whilst holding the Kicker's Tee securely, twist the ball envelope anti-clockwise to remove.
3. Install the recommend lamp.
4. Replace the twist lock ball envelope. Reinsert the ball into the Kicker's Tee and rotate the ball until it clicks into place.
5. Connect to a suitable electrical outlet.

Dispose of packaging appropriately and recycle where possible.